



MMS-D206-540

DART AEROSPACE LTD
2071 Malaview Avenue
Sidney, BC, V8L 5X6
Canada

Tel: 604 656 2262
Fax: 604 656 2993

MAINTENANCE MANUAL SUPPLEMENT

Heli-Utility-BasketTM

(UTILITY BASKET INSTALLATION)

BELL 206A/B/L/L1/L3/L4 MODELS

Prepared By: Jim Bradley
Revision: **B**
Date: 95.12.12



THIS SUPPLEMENT IS TO BE USED IN CONJUNCTION WITH:

- a) The aircraft Maintenance and Overhaul Instruction Manual.
- b) AC.43.13.1A and 2A, acceptable methods, techniques, and practices.
- c) Dart installation drawing D206-540.

DAILY INSPECTION

- a) Check physical integrity and security of the BASKET.
- b) Check condition of the latches and hinges.

100 HOUR INSPECTION

(or if damage found on daily inspection)

- a) Inspect for damage or wear.
- b) Replace damaged or worn parts per drawing D206-540.

Revision : **B**

Date : 95.12.12