

4.3.2 SECTION B – POWERPLANT SECTION: Applicable 250-C30 series engine

SECTION	FREQUENCY
B 015 NT	Every 150 Hours. No Tolerance
B 0300 NT	Every 300 Hours or 12 Months whichever comes first. No Tolerance
B 0301 NT	Every 300 Hours or 12 Months whichever comes first. No Tolerance

4.3.3 SECTION C - INSTRUCTIONS FOR CONTINUED AIRWORTHINESS: Applicable to BELL 206L Series Helicopters

SECTION	FREQUENCY
C 0010	Every 300 Hours or 12 Months whichever comes first, occurs after C 0060.
C 0020	Every 300 Hours or 12 Months whichever comes first, occurs after C 0010.
C 0030	Every 300 Hours or 12 Months whichever comes first, occurs after C 0020.
C 0040	Every 300 Hours or 12 Months whichever comes first, occurs after C 0030.
C 0050	Every 300 Hours or 12 Months whichever comes first, occurs after C 0040.
C 0060	Every 300 Hours or 12 Months whichever comes first, occurs after C 0050.
NOTE: The above inspections must be performed consecutively.	
C 1700	Every 12 Months
C 1710	Every 12 Months
C 0360	Every 36 Months
C 0550	Every 500 Hours or 12 Months whichever comes first

4.4 OPERATIONAL CHECKS AND OPERATIONAL CHECK FLIGHTS

See the "Maritime Helicopters Operations Manual," as revised, for complete instructions concerning operational checks and flights.

4.5 INSPECTIONS AWAY FROM HOME BASE

Inspections away from home base shall be conducted in accordance with the Approved Aircraft Inspection Program and the "Maritime Helicopters Operations Manual," as revised.