

Page No: 3
Revision: Temp Rev #1
Issue Date: 05/10/21

SECTION: C 0302 – ICA OF INSTALLED EQUIPMENT
TYPE: 300 HOUR / 12 MONTH INSPECTION
NOTE:

MAINTENANCE ACTION		REFERENCE	MECHANIC'S INITIALS
C 0302.6 AAI FLOATSTEP KIT – AA-01161			
6.1	Inspect the step brackets, clamp brackets and step assemblies for nicks, scratches, dents, corrosion or cracks NOTE: Particular care should be taken to inspect in the areas of the bolts and screws in the step assemblies and brackets. NOTE: The indications of corrosion are: 1) corrosion deposits (a white gray powder on aluminum and amber or brown powder on steel) 2) pits in the part surfaces 3) blisters on the part surfaces.		
6.2	Remove safety wire.		
6.3	Check the torque values on the attaching fasteners. Re-torque fasteners as required.	Table 2	
6.4	Install new safety wire (.32 diameter)	Figure 7	
C 0302.7 POST INSPECTION			
7.1	Inspect for operation and leaks.		
7.2	Replace or close all applicable trim panels, covers, access and inspection doors/covers as necessary.		
7.3	Perform Functional Check Flight if required per Rotorcraft Flight Manual and/or Manufacturer ICA.		
7.4	Make an entry in the appropriate logbook (refer to the following page for wording of approval for return to service).		